

Contents of the Dent Lifter Set Art. No. 0691 500 111

Item	Description	Set Cont.	Art. No.	P. Qty.
1	Sliding hammer	1	0691 500 112	1
2	Sticker (0.5kg special adhesive, Ø 12mm)	1	0890 100 057	1
3	Adapter, round, stiff (yellow), Ø 40mm Suitable for round and large deformations, the adapter material enables high tensile forces and stress	10	0691 500 115	10
4	Adapter, round, flexible (purple), Ø 40mm Suitable for round and sharp-edged deformations, the adapter material can be adjusted to the shape of the dent by means of heating	10	0691 500 116	10
5	Adapter, oval, stiff (yellow), 47 x 33mm Suitable for scratches and grazing marks, the adapter material enables high tensile forces and stress	10	0691 500 117	10
6	Adapter, oval, flexible (purple), 47 x 33mm Suitable for scratches and grazing marks, the adapter material can be adjusted to the shape of the dent by means of heating	10	0691 500 118	10
7	Adapter, round, small (blue), Ø 35mm Suitable for round and small deformations, the adapter material can be adjusted to the shape of the dent by means of heating	10	0691 500 121	10
	Adapter, barrel-shaped (purple), 37 x 33mm Suitable for grazing marks, the adapters are placed next to each other and then alternately pulled	–	0691 500 122	10
8	Installation attachment for adapter (for optimum installation and removal)	1	0691 500 114	1
9	Special spatula, flexible (adhesive residues can be easily removed from it)	1	0691 500 120	1
10	Gloves, size 9 (protect against undesired burns)	1	0899 410 09	1
11	Grinding fleece (to roughen adapters for initial use)	2	0585 44 600	10
12	Cleaning towels (optimum for use with acetone and pre-cleaner)	50	0899 800 901	500
13	Acetone cleaner (cleaning the dents without residues)	1	0893 460	1
14	Pre-cleaner (careful removal of the melting glue)	1	0893 200 1	1

Application



1. Clean dent using acetone cleaner.



2. Install suitable adapter on installation attachment and apply special adhesive to centre.



3. Glue adapter to deepest spot and cool using compressed air.



4. Hand sliding hammer into the adapter and straighten dent.



5. Using a hot air gun heat the adapter up to approx. 150°C and push it away to the side using the installation attachment.



6. Heat up the adhesive residue and remove it using special spatula.



7. Remove remaining adhesive residue using pre-cleaner.



8. Done!